

Antenna wiring and Matching board ACA 100

All Inomatic antennas are wired with 3 loops → 0 – Loop, 8 – Loop, 88 – Loop

